










AMAZON TEDDY

ASSEMBLY INSTRUCTIONS


DINING CHAIR MODEL#: UDC22009



Icons for assembly: a person icon labeled 'X1', a clock icon labeled '0:10', and a person icon labeled 'X1'.

| | | | | | | | |
|--|--|--|--|--|--|--|--|
|  ① X1 |  ② X1 |  ③ X1 |  A X1 |  B X1 |  C X5 |  D X1 |  E X4 |
|--|--|--|--|--|--|--|--|

1



2

